

We Will Set Up Ram Board Runners, And Plastic Barricades At All Work Areas Typ.
We Will Vacuum, And Wipe Down All Work Areas Once Work Is Completed. We Will Need Approx. 7 Days To Complete This Work. 5 Days For Conduit Work, And 2 Days For F/A Terminations.

SDSU FacilitiesLink

<https://sdsu.metabim.com/>

PUBLISHED BY:
SDSU Administration

09/06/2018

CAMPUS: 65/Q

CENTER: 00

ASSET: 019

ENGINEERING

SECOND FLOOR

NOT TO SCALE
DIGITAL PLOT

A3

200
201
202
202F
202G
203
203E
205
206
207
208A
217
218
219
220
221
221B
222
2000

SDSU FacilitiesLink

CAMPUS: 65/Q
CENTER: 00
ASSET: 019

SECOND FLOOR

NOT TO SCALE
DIGITAL PLOT

09/06/2018

<https://sdsu.metabim.com/>

A3